

Active surface contact temperature sensor (0...10 V) for pipe applications. Spring loaded brass contact pin to ensure fast response and accurate reading.

Technical data sheet

22HT-52





Type Overview

Technical data

	Туре	Output signal active temperature			
	22HT-52	05 V, 010 V			
Electrical Data	Nominal voltage	AC/DC 24	24 V		
	Nominal voltage range	AC 21.6	.26.4 V / DC 13.526.4 V		
	Power consumption AC	0.8 VA			
	Power consumption DC	0.4 W			
	Electrical connection	Pluggable spring loaded terminal block max. 2.5 mm ²			
	Cable entry		nd with strain re uit adapter inclu		ı (1/2"
Functional Data	Sensor Technology	based on Pt1000 1/3 DIN			
	Application	water			
	Multirange	8 measur	ing ranges selec	table	
	Voltage output	1 x 05 V	, 010 V, min. r	esistance 5 kΩ	2
	Output signal active note	output 0	5/10 V with jun	nper adjustabl	e
Measuring Data	Measured values	Temperature			
	Measuring range temperature				
		Active sensor: range selectable			
		Attention: max. measuring temperature is restricted by max. fluid temperature (see Sa data)			
				e Salety	
		Setting	Range [°C]	Range [°F]	Factory setting
		S0	-5050	-30130	5
		S1	-10120	0250	
		S2	050	40140	
		S3	0250	30480	
		S4 S5	-1535 0100	0100 40240	
		55 S6	-2080	40240	
		S7	0160	0150	
	Accuracy temperature active	±0.5°C @ 21°C [±0.9°F @ 70°F] @ measuring range setting S2 and S4			
	Long-term stability	±0.07°F p.a. @ 70°F [±0.04°C p.a. @ 21°C] [±39.2°F p.a. @ 69.8°F]			
	Time constant τ (63%) on water pipe				
Materials	Cable gland	PA6, blacl	k		



	 nic		- 1			- 1
- 1 -		4-11			T a l	- 1
				C 🖉 🖉		-

Materials	Housing	Cover: PC, orange Bottom: PC, orange Seal: NBR70, black UV resistant UL94 5VA	
Safety Data	Protection class IEC/EN	III, Protective Extra-Low Voltage (PELV)	
	Power source UL	Class 2 Supply	
	Degree of protection IEC/EN	IP54	
	Degree of protection NEMA/UL	NEMA 1	
	Enclosure	UL Enclosure Type 1	
	EU Conformity	CE Marking	
	Certification IEC/EN	IEC/EN 60730-1	
	Quality Standard	ISO 9001	
	UL 2043 Compliant	Suitable for use in air plenums per Section 300.22(C) of the NEC and Section 602 of the IMC	
	Pollution degree	2	
	Ambient humidity	Max. 95% RH, non-condensing	
	Ambient temperature	-3550°C [-30122°F]	
	Fluid temperature	-30160°F [-3570°C]	
	Housing surface temperature	max. 160°F [70°C]	

Safety Notes



This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorized modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.

Ensure all power is disconnected before installing. Do not connect to live/operating equipment. Only authorized specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.

The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.

Remarks

General Remarks Concerning Sensors

When using lengthy connection wires (depending on the cross section used) the measuring result might be falsified due to a voltage drop at the common GND-wire (caused by the voltage current and the line resistance). In this case, 2 GND-wires must be wired to the sensor - one for supply voltage and one for the measuring current.

Sensing devices with a transducer should always be operated in the middle of the measuring range to avoid deviations at the measuring end points. The ambient temperature of transducer electronics should be kept constant. The transducers must be operated at a constant supply voltage (± 0.2 V). When switching the supply voltage on/off, onsite power surges must be avoided.



Technical data sheet


A-22P-A44

Build-up of self-heating by electrical dissipative power	Temperature sensors with electronic components always have a dissipative power which affects the temperature measurement of the ambient air. The dissipation in active temperature sensors shows a linear increase with rising operating voltage. The dissipative power should be taken into account when measuring temperature.		
	In case of a fixed operating voltage (\pm 0.2 V), this is normally done by adding or reducing a constant offset value. As Belimo transducers work with a variable operating voltage, for reasons of production engineering only one operating voltage can be taken into consideration. Transducers 010 V / 420 mA have a standard setting at an operating voltage of DC 24 V. This means that at this voltage, the expected measuring error of the output signal will be the least. For other operating voltages, the offset error will be increased by a changing power loss of the sensor electronics.		
	If a readjustment directly at the active sensor should be necessary during later operation, thi can be done with the following adjustment methods.		
	- For sensors with NFC or dongle with the corresponding Belimo app		
	- For sensors with a trimming potentiometer on the sensor board		
	- For bus sensors via bus interface with a corresponding software variable		
Parts included			
	Fixing strap for pipes up to ø110 mm 1/2" NPT conduit adapter		
Accessories			
Optional accessories	Description	Туре	
	Fixing strap, with thermal paste for pipes ø20110 mm [0.84.3"] Fixing strap, with thermal paste for pipes ø20250 mm [0.89.8"]	A-22P-A40 A-22P-A42	

Syringe with thermal paste

www.belimo.com







The adjustment of the measuring ranges is made by changing the bonding jumpers. The output value in the new measuring range is available after 2 seconds.

Setting S0	Range [°C] -5050	Range [°F] -30130	Factory setting
S1	-10120	0250	
S2	050	40140	
S3	0250	30480	
S4	-1535	0100	
S5	0100	40240	\checkmark
S6	-2080	4090	
S7	0160	0150	







Further documentation

• Installation instructions